



1 Remove the new cartridge from its bag.



2 Place the cartridge into a container of cold tap water and shake the filter for 10 to 20 seconds to remove any air bubbles.



3 Clean the cartridge then place it into the filter holder of the pitcher.



4 Pour cold water into the top section of your filter pitcher. Then let the water filter through.



5 Repeat stage 4 two more times, discarding the filtered water.

IMPORTANT

To reduce the risk associated with the ingestion of contaminants, do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

When washing the cartridge do NOT use soapy water.

It is advised that the filtered water be stored in a fridge and be used within 48 hours.

Replace the filter cartridge after the total capacity has been reached (or after 1 month).

Do not use the cartridge beyond its recommended life.